


# Large Scale Visualization with ParaView

ATPESC 2021


Dan Lipsa, Staff R&D Engineer,  
Kitware, Inc.



# Outline

---


- Kitware
- Introduction
- Basic Usage
- Visualizing Large Models



# Kitware

---


- Open-source, software R&D company
- Core areas of expertise
  - Computer Vision
  - Data and Analytics
  - HPC and Visualization
  - Medical Computing
  - Software Process



# To Follow Along...

---

- Install ParaView 5.9.1
  - <http://www.paraview.org> → Download




# Introduction

# What is ParaView?

---

- An open-source (BSD 3 Clause License), scalable, multi-platform visualization application based on VTK
- Processing paradigms:
  - distributed computing (MPI)
  - shared memory multiprocessing (vtkSMPTTools)
  - GPU processing (vtk-m).
- Rendering
  - Physically Based Rendering
  - Ray tracing (Intel OSPRay, NVIDIA OptiX)
- Has an open, flexible, and intuitive user interface
- Has an extensible, **modular architecture** based on open standards


# ParaView on the Desktop



# ParaView on the Web

Visualizer, Glance (vtk.js)

<https://blog.kitware.com/vis-on-the-web/>





# ParaView Scripting - Python


---



Python scripts can control ParaView, with or without the GUI, in order to create reproducible and customizable visualizations.

# ParaView Immersive

---




# ParaView for HPC

---




# ParaView Catalyst



Community Atmosphere Model (CAM5) 2D (PS) 3D data (T), Spectral Element dynamic module.

# ParaView Custom Application VeloView

---



Visualization of 3D LIDAR data.

# Current ParaView Usage

---

- Used by academic, government, and commercial institutions worldwide.
- Downloaded ~135K times per year.
- HPCwire Editors' Choice 2010/2016 and HPCwire Readers' Choice 2010/2012/2015 Awards for Best Visualization Product or Technology.




# Data Ranges

---


- Used for all ranges of data size.
- Landmarks of usage:
  - 6 billion structured cells (2005).
  - Billions of AMR cells (2008).
  - 6.33 billion unstructured cells in Catalyst (2016).
  - Scaling test over 1 Trillion cells (2010).




# Data Types




Uniform Rectilinear  
(vtkImageData)




Non-Uniform Rectilinear  
(vtkRectilinearData)



Curvilinear  
(vtkStructuredData)



Polygonal  
(vtkPolyData)




Unstructured Grid  
(vtkUnstructuredGrid)

- Multi-block
- Hierarchical Adaptive Mesh Refinement (AMR)
- Hierarchical Uniform AMR
- Octree



# More Information

---



# Basic Usage

# User Interface


Menu Bar

Toolbars

Pipeline Browser

Properties Panel

Information Panel



# Creating a Cylinder Source


---

1. Go to the Sources menu and select Cylinder.
2. Click the Apply button to accept the default parameters.




# Simple Camera Manipulation


- Drag left, middle, right buttons for rotate, pan, zoom.
  - Also use Shift, Ctrl modifiers (see Edit > Setting > Camera)
  - Also try holding down x, y, or z.




# Creating a Cylinder Source

---


1. Go to the Source menu and select Cylinder.
2. Click the Apply button to accept the default parameters. 
3. Increase the Resolution parameter.



4. Click the  button again.


# Pipeline Object Controls

---



Pipeline objects {  
Sources  
Filters  
Readers  
Extractors


# Display Properties






# Change Display Properties

---


1. Scroll down to the Display group.
2. Click the  Edit button. (This button is replicated in the toolbar.)
3. Select a new color for the cylinder.

# View Properties




# Change View Properties

---

1. Scroll down to the Display group.
2. Click the  Edit button. (This button is replicated in the toolbar.)
3. Select a new color for the cylinder.
4. Scroll down to the View group.
5. Turn on the Axis Grid.

# Advanced Properties

Search  
Properties



Toggle  
Advanced  
Properties

# Searching Properties

---

1. Type “specular” in the properties search box
2. Change Specular value to 1 (makes the cylinder shiny)

# Searching Properties

---



1. Type “specular” in the properties search box
2. Change Specular value to 1 (makes the cylinder shiny)

Other interesting properties:

- Axes Grid
- Opacity

# Changing the Color Palette

1. Make sure the orientation axes are visible in the lower left corner.




2. Click the color palette button  and change the colors.



3. Try several color palettes.

# Color Palettes

 → Edit Current Palette...





# Undo Redo

---



Undo



Redo



Camera  
Undo



Camera  
Redo


# Supported File Types

---

- ParaView Data (.pvd)
- VTK (.vtp, .vtu, .vti, .vts, .vtr)
- VTK Legacy (.vtk)
- VTK Multi Block (.vtm, .vtmb, .vtmg, .vthd, .vthb)
- Partitioned VTK (.pvtu, .pvti, .pvts, .pvtr)
- ADAPT (.nc, .cdf, .elev, .ncd)
- ANALYZE (.img, .hdr)
- ANSYS (.inp)
- AVS UCD (.inp)
- BOV (.bov)
- BYU (.g)
- CAM NetCDF (.nc, .ncdf)
- CCSM MTSD (.nc, .cdf, .elev, .ncd)
- CCSM STSD (.nc, .cdf, .elev, .ncd)
- CEAUcd (.ucd, .inp)
- CGNS (.cgns)
- CMAT (.cmat)
- CML (.cml)
- CTRL (.ctrl)
- Chombo (.hdf5, .h5)
- Claw (.claw)
- Comma Separated Values (.csv)
- Cosmology Files (.cosmo, .gadget2)
- Curve2D (.curve, .ultra, .ult, .u)
- DDCMD (.ddcmd)
- Digital Elevation Map (.dem)
- Dyna3D (.dyn)
- EnSight (.case, .sos)
- Enzo boundary and hierarchy
- ExodusII (.g, .e, .exe, .ex2, .ex2v., etc)
- ExtrudedVol (.exvol)
- FVCOM (MTMD, MTSD, Particle, STSD)
- Facet Polygonal Data
- Flash multiblock files
- Fluent Case Files (.cas)
- GGCM (.3df, .mer)
- GTC (.h5)
- GULP (.trg)
- Gadget (.gadget)
- Gaussian Cube File (.cube)
- JPEG Image (.jpg, .jpeg)
- LAMPPS Dump (.dump)
- LAMPPS Structure Files
- LODI (.nc, .cdf, .elev, .ncd)
- LODI Particle (.nc, .cdf, .elev, .ncd)
- LS-DYNA (.k, .lsdyna, .d3plot, .d3plot)
- M3DCI (.h5)
- MFIX Unstructured Grid (.RES)
- MM5 (.mm5)
- MPAS NetCDF (.nc, .ncdf)
- Meta Image (.mhd, .mha)
- Miranda (.mir, .raw)
- Multilevel 3d Plasma (.m3d, .h5)
- NASTRAN (.nas, .f06)
- Nek5000 Files
- Nrrd Raw Image (.nrrd, .nhdr)
- OpenFOAM Files (.foam)
- PATRAN (.neu)
- PFLOTTRAN (.h5)
- PLOT2D (.p2d)
- PLOT3D (.xyz, .q, .x, .vp3d)
- PLY Polygonal File Format
- PNG Image Files
- POP Ocean Files
- ParaDIS Files
- Phasta Files (.pht)
- Pixie Files (.h5)
- ProSTAR (.cel, .vrt)
- Protein Data Bank (.pdb, .ent, .pdb)
- Raw Image Files
- Raw NRRD image files (.nrrd)
- SAMRAI (.samrai)
- SAR (.SAR, .sar)
- SAS (.sasgeom, .sas, .sasdata)
- SESAME Tables
- SLAC netCDF mesh and mode data
- SLAC netCDF particle data
- Silo (.silo, .pdb)
- Spheral (.spherical, .sv)
- SpyPlot CTH
- SpyPlot (.case)
- SpyPlot History (.hscth)
- Stereo Lithography (.stl)
- TFT Files
- TIFF Image Files
- Tsurf Files
- Tecplot ASCII (.tec, .tp)
- Tecplot Binary (.plt)
- Tetrad (.hdf5, .h5)
- UNIC (.h5)
- VASP CHGCA (.CHG)
- VASP OUT (.OUT)
- VASP POSTCAR (.POS)
- VPIC (.vpc)
- VRML (.vrl)
- Velodyne (.vld, .rst)
- VizSchema (.h5, .vsh5)
- Wavefront Polygonal Data (.obj)
- WindBlade (.wind)
- XDMF and hdf5 (.xmf, .xdmf)
- XMol Molecule

# Custom Data Import: Prototype with Python

- A “programmable source” lets you program data readers right in the GUI.
- Uses wrappings for the basic VTK classes.
- Or use Python or C++ plugin.



```
Output Data Set Type: vtkPolyData

Script:

import random


output = self.GetOutput()
numpoints = 12

points = vtk.vtkPoints()
for p in xrange(numpoints):
    points.InsertNextPoint(random.random())
output.SetPoints(points)

verts = vtk.vtkCellArray()
for c in xrange(numpoints):
    verts.InsertNextCell(1)
    verts.InsertCellPoint(c)
output.SetVerts(verts)
```

# Load disk\_out\_ref.ex2


1. Open the file disk\_out\_ref.ex2 from the examples directory.



# Load disk\_out\_ref.ex2



---

1. Open the file disk\_out\_ref.ex2 from the examples directory.
2. Load all data variables.




3. Click 

# Data Representation



# Filters Menu



~200 filters

Status bar:

- Short description
- Reason why is grayed

# Common Filters

---



Calculator



Contour



Clip



Slice



Threshold



Extract Subset



Glyph



Stream Tracer



Warp (vector)



Group Datasets




Extract Level



# Quick Launch

---



- Used for searching for filters by name
- Keyboard shortcut
  - Ctrl-space for Windows & Linux
  - Alt-space for Mac

# Apply Contour

---


1. Select disk\_out\_ref.ex2 in the pipeline browser.
2. Press the contour filter.



Specify the data you  
apply the filter on



# Apply Contour

3. Change parameters to create an isosurface at Temp = 400K.




# Apply Contour

---

1. Select disk\_out\_ref.ex2 in the pipeline browser.
2. Select the contour filter. 
3. Change parameters to create an isosurface at Temp = 400K.
4. 





# Apply ExtractSurface

---



1. Select `disk_out_ref.ex2` in the pipeline browser.
2. From the quick launch, select Extract Surface.
3. 

# Apply ExtractSurface, Clip



---

1. Select disk\_out\_ref.ex2 in the pipeline browser.
2. From the quick launch, select Extract Surface.
3.  Apply
4. **Select ...** Create a clip filter. 
5. Uncheck Show Plane.  Show Plane
6.  Apply

# Pipeline Browser Structure





# Pipeline Browser Structure






# Pipeline Browser Structure







# Multiview





# Multiview

---

1. Select disk\_out\_ref.ex2 in the pipeline browser.
2. Add Clip filter.
3. Uncheck Show Plane.  Show Plane
4. 
5. Hide Clip2 



# Multiview

---

6. Split the view horizontally. 
7. Make Clip2 visible. 
8. Color surface by Temp.




# Multiview

---



6. Split the view horizontally. 
7. Make Clip2 visible. 
8. Color surface by Temp.
9. Right-click view, Link Camera...
10. Click other view.

# Multiview



---

6. Split the view horizontally. 
7. Make Clip1 visible. 
8. Color surface by Temp.
9. Right-click view, Link Camera...
10. Click other view.
11. Click  -x and zoom in a bit.

# Modifying Views



# Modifying Views






# Reset ParaView





---

Edit → Reset Session








# Streamlines

---

1. Open disk\_out\_ref.ex2. Load all variables. 
2. Add Stream Tracer. 
3. Change Seed Type to Point Source.
4. Uncheck Show Sphere. 
5. 




# Streamlines

---

1. Open disk\_out\_ref.ex2. Load all variables. 
2. Add Stream Tracer. 
3. Change Seed Type to Point Source.
4. Uncheck Show Sphere. 
5. 
6. From the quick launch, select Tube
7. 

# Getting Fancy


---

8. Select StreamTracer1.
9. Add Glyph filter. 
10. Change Glyph Type to Cone.
11. Change Orientation Array and Scale Array to V.
12. Change Vector Scale Mode to Scale By Magnitude.
13. Click reset  next to Scale Factor.
14. 
15. Color by Temp.

# Reset ParaView


---

Edit → Reset Session




# Common Data Analysis Filters


---



Extract Selection



Plot Global Variables Over Time



Plot Over Line



Plot Selection Over Time



Probe Location

# Plotting


1. Open disk\_out\_ref.ex2. Load all variables. 

2. Clip,  uncheck, ☒ Show Plane , 

3. Select disk\_out\_ref.ex2.

4. Add Plot Over Line filter. 

# 3D Widgets





# Placing 3D Line Widget Endpoints

---

- Use the p key to place alternating points.
  - Ctrl+p places at nearest mesh point.
- Use the 1 or 2 key to place the start or end point.
  - Ctrl+1 or Ctrl+2 places at mesh point.
- Drag the endpoints.
  - Use x, y, or z key to constrain to axis.
- Use widgets in Properties panel
  - E.g. Use Z Axis button and then edit points to place from (0,0,0) to (0, 0, 10).

# Plotting

---

1. Open disk\_out\_ref.ex2. Load all variables.  Apply

2. Clip,  uncheck, ☒ Show Plane ,  Apply


3. Select disk\_out\_ref.ex2.

4. Add Plot Over Line filter. 

5. Once line is satisfactorily located,  Apply



# Interacting with Plots

---

- Left, middle, right buttons to pan, zoom.
- Mouse wheel to zoom.
- Reset view to plot ranges. 

# Plots are Views

- Move them like Views.
- Save screenshots.




# Adjusting Plots

---


1. In Display section of properties panel, turn off all variables except Temp and Pres.
2. Select Pres in the Display options.
3. Change Chart Axis to Bottom – Right.
4. Verify the relationship between temperature and pressure.

# Volume Rendering

---



1. Open disk\_out\_ref.ex2. Load all variables. 
2. Change variable viewed to Temp.
3. Change representation to Volume.
4. In the Are you Sure dialog box, click Yes.

# Transfer Function Editor



# Modify Transfer Function

---


1. Select disk\_out\_ref.ex2.
2. Click Edit Color Map  .
3. Click Choose preset  .
4. Select Black-Body Radiation.  
Apply. Close.
5. Try adding and changing control points.



# Reset ParaView




---

Edit → Reset Session




# Query-Based Selection

---

1. Open can.ex2. All variables. 
2. Go to last time step. 
3. Edit → Find Data. 
4. Top combo box: find Cells.
5. Next row: EQPS, is  $\geq$ , and 1.5.
6. Click Run Selection Query.

# Query-Based Selection



The image shows the ParaView 3.8.0 interface. The main window displays a 3D surface plot of a wavy surface. A 'Find Data' dialog box is open, showing the 'Cell' selection criteria for the 'can.ex2' dataset. The dialog includes a 'Run Selection Query' button and a 'Query Results' table.

**Find Data Dialog Box:**

- Find: **Cell** from **can.ex2**
- EQPS: **is >=** **1.5**
- Block ID: **is**

**Query Results Table:**

	EQPS	ObjectId	GlobalElementId	PedigreeElement
0	1.97048	1	36	36
1	1.51309	1	37	37
2	2.13094	1	76	76

Below the table, there are options for 'Selection Color' (a pink circle), 'Labels' (set to 'None'), and 'Label Color'. At the bottom of the dialog are buttons for 'Extract Selection', 'Plot Selection Over Time', and 'Close'.

# Brush Selection

---



Surface Cell Selection  
(shortcut: s)



Surface Point Selection  
(shortcut: d)




Through Cell Selection  
(shortcut: f)



Through Point Selection  
(shortcut: g)



Select Cells (polygon)



Select Points (polygon)



Block Selection  
(shortcut: b)



Interactively Select Cells



Interactively Select Points







Hover Point Query



Hover Cell Query

# Adding Labels


---

1. Go to the last time step. 
2. Interactively Select Cells 
3. Open Find Data. 
4. In the Cell Labels chooser, select EQPS.
5. Try again: Interactively Select Cells 

# Reset ParaView

---

Edit → Reset Session



# Python Scripting

---

- Tools > Start Trace
- Build visualization pipeline with UI
- Tools > End Trace
- Save Python script




# Visualizing Large Models



# Data Parallel Pipelines


---

- Duplicate pipelines run independently on different partitions of data.



# Data Parallel Pipelines


- Many operations will work regardless.
  - Example: Clipping.



# Data Parallel Pipelines


---

- Many operations will work regardless.
  - Example: Clipping.




# Data Parallel Pipelines




- Many operations will work regardless.
  - Example: Clipping.



- Will discuss those that don't later



# ParaView's Running Modes


Builtin aka Standalone aka Serial		<p>all components within one process (client may be GUI or pvpython)</p> <pre>paraview    pvpython</pre>
Combined Server		<p>data processing and parallel rendering in MPI job of combined processes. control from TCP connected client.</p> <pre>mpiexec -n x pvserver &amp; paraview # or pvpython #+Connect</pre>
Batch		<p>server is an MPI job which directly runs a python script</p> <pre>mpiexec -n x pvbatch \ vis_script.py</pre>

DS = data server

RS = render server

# Fetch Server Configuration

- File > Connect > Fetch Servers



# Connect Unix/Mac

**Mac Os: Install Xquartz**

Connection Options for "COOLEY@ANL"

Xterm executable	/opt/X11/bin/xterm	...
SSH executable	ssh	...
Remote machine	cooley.alcf.anl.gov	
Username	danlipa	
ParaView version	v5.4.0	
Client port	11111	⬆ ⬇ ⬆
Server port	42844	⬆ ⬇ ⬆
Number of nodes to reserve	2	⬆ ⬇ ⬆
Number of minutes to reserve	10	⬆ ⬇ ⬆
Account	ATPESC2017	
Queue	training	
Job name	paraview_server	


Cancel OK



# Connect Windows

**Windows:** Install PuTTY

quotes are required



Connection Options for "windows to COOLEY"

SSH executable 6)\PuTTY\plink.exe) ...

Remote machine cooley.alcf.anl.gov

Username YOURUSERNAME

ParaView version v5.4.0

Client port 11111

Server port 22395

Number of nodes to reserve 2

Number of minutes to reserve 20

Account YOURPROJECT

Queue default





Job name paraview\_server

Cancel OK

# Advanced Data Parallel Pipelines

---


- Some operations will have problems.
  - Example: External Faces



# Advanced Data Parallel Pipelines

---


- Ghost cells can solve most of these problems.



# Advanced Data Parallel Pipelines

---


- Ghost cells can solve most of these problems.




# Balanced Partitioning + Ghost Cells


- Automatic when reading structured data.
- For unstructured data:
  - Ghost Level Generator: creates ghost cells (if data is partitioned on disk)
  - D3: also creates a balanced partition.

Extract Surface  
without ghost  
cells



Extract Surface  
after D3





Thank you!  
Questions?